

# Visual Guide to FX Replacement



The old heater needing to be replaced.

1. Turn off power at breaker
2. Take off grill
3. Remove interior.

Remove wire nuts from interior.



Remove remaining screws and take wiring out of wall can.

Trim wall opening for new King W Series wall box..

Apply power wires with grommet and ground wall box. Insert into wall leaving 1/2 inch



Attach can to stud on one side and use 2 screws just behind the wall board to prevent the other side from moving forward.

Move wiring to left and insert interior into wall can and screw interior at top of can.

Turn power on and test.

Apply grill and your finished.  
Model: W2420

 **king** electrical mfg. company

9131 10th Ave South • Seattle WA 98108  
(206) 762-0400 fax (206) 763-7738